

User Guide

Fleet Clean Pre-Spray

22001105/20Lt 2201106/205Lt 22001107/1000Lt IBC

<i>Application</i>	Low Alkalinity Vehicle Pre-Spray
<i>Features & Benefits</i>	<ul style="list-style-type: none"> • Lower chemical consumption when used correctly • Powerful pre-cleaning • Safe on delicate paint work • Safe for food vehicles • Suitable for use with oil separators
<i>Dilution</i>	<p>Light Soiling: 1% (1:100)</p> <p>Medium Soiling: 2% (1:50)</p> <p>Heavy Soiling: 3% (1:30)</p>
<i>Equipment Required</i>	<ul style="list-style-type: none"> • Fixed gantry/low pressure spray arch • Rozone low-pressure pre-spray equipment • Alternatively low pressure chemical spray canister • Source of high pressure fresh water for rinsing
<i>Use Instructions</i>	<ol style="list-style-type: none"> 1. Fleet Clean Pre-Spray can be used hot or cold. For best results use hot. 2. If using a hand held low pressure sprayer dilute to desired concentration in the spray canister. 3. If using the Rozone Low Pressure Pre-spray Equipment set the chemical feed to the desired concentration. 4. Apply detergent to the vehicle starting at the bottom and working upwards. 5. In hot weather pre-cool paintwork with cold water and do not allow detergent to dry onto the surface. 6. Rinse off with high pressure cold water.
<i>Hints & Tips</i>	<i>For areas of heavy soiling higher concentrations can be used with longer dwell times.</i>
<i>Precautions</i>	<p>Always observe precautions in material safety data sheet.</p> <p>Do not allow chemical to dry onto paint work.</p>