

User Guide

Heavy Duty TFR

22001102/20Lt 22001103/205Lt 22001104/1000Lt IBC

<i>Application</i>	Powerful Traffic Film Remover for Heavy Duty Applications
<i>Features & Benefits</i>	<ul style="list-style-type: none"> • Super Concentrate - Excellent Economy in Use • High Foam Formulation – Enhanced Detergency • Low Caustic Formula – Better Rinsing, Better Safety
<i>Dilution</i>	<p>Application</p> <p>HD TFR recommended dilutions*:</p> <p style="padding-left: 40px;">Light Soiling: 1% (100:1)</p> <p style="padding-left: 40px;">Medium Soiling 2% (50:1)</p> <p style="padding-left: 40px;">Heavy Soiling 3% (30:1)</p> <p>*Refer to Pressure Washer Specifications/Instructions</p>
<i>Equipment Required</i>	<ul style="list-style-type: none"> • Pressure washer (variable ratio's) • May require to pre-dilute depending upon Pressure Washer specification • Bucket/Mop
<i>Use Instructions</i>	<ol style="list-style-type: none"> 1. Rozone Heavy Duty TFR; Use hot or cold in the normal way via a pressure washer. For best results use hot. 2. Apply the solution to the surface of the vehicle at low or high, pressure working from the bottom of the vehicle upward to avoid cleaning-streaks over dry areas of the vehicle. 3. In hot weather cool paintwork with water before applying chemical. Do not allow the chemical to dry on the surface. 4. Rinse with a bucket, hose or pressure washer from the top of the vehicle rinsing downwards evenly and methodically.
<i>Hints & Tips</i>	<p><i>For a perfect spot-free finish dry with a squeegee or chamois.</i></p> <p><i>For the very best results, use warm water (<60°C at machine)</i></p> <p><i>To avoid cleaning-streaks: Apply bottom up; Rinse top down.</i></p>
<i>Precautions</i>	<p>Always observe precautions in material safety data sheet,</p> <p>For fresh or damaged paint/livery always check compatibility on an inconspicuous area first.</p>