

# User Guide

## Maintenance Spray & Penetrant

22001138/6x500ml

22001139/2x5Lt

<b><i>Application</i></b>	<b>Dewatering, Anti-Corrosion and Lubrication</b>
<b><i>Features &amp; Benefits</i></b>	<ul style="list-style-type: none"> <li>• Multi-purpose maintenance spray</li> <li>• Excellent penetration: frees seized joints &amp; threads</li> <li>• Corrosion protection</li> <li>• Leaves a light lubricant film on sensitive metals</li> </ul>
<b><i>Dilution</i></b>	This product is supplied ready to use. Do not dilute.
<b><i>Equipment Required</i></b>	<ul style="list-style-type: none"> <li>• Spray bottle</li> <li>• Immersion tank</li> <li>• Rag/Swab</li> </ul>
<b><i>Use Instructions</i></b>	<p>Rozone Maintenance Spray &amp; Penetrant may be applied by jet spray, dip tank or by rag.</p> <ol style="list-style-type: none"> <li>1. Clean surface and remove corrosion.</li> <li>2. Dry surface</li> <li>3. Spray directly onto surface</li> <li>4. Allow to dry</li> </ol>
<b><i>Hints &amp; Tips</i></b>	<p><i>Solvents cleaners like white spirit or petrol can damage the product protective film.</i></p> <p><i>Drying time is approximately 1hour</i></p>
<b><i>Precautions</i></b>	<p><b>Always follow safety precautions on label or safety data sheet.</b></p> <p>Product may soften natural rubber seals, latex etc.</p>