

# User Guide

## CFT Fibre & Fabric Rinse Concentrate

22000682/2x5Lt

<b><i>Application</i></b>	<b>Acidic Rinse and Browning Neutraliser</b>
<b><i>Features &amp; Benefits</i></b>	<ul style="list-style-type: none"> <li>• Low pH rinse</li> <li>• Concentrated &amp; Economical</li> <li>• Suitable for use on most textiles</li> </ul>
<b><i>Dilution</i></b>	2% (20ml made up to a litre)
<b><i>Equipment Required</i></b>	Extraction machines / Sprayer
<b><i>Use Instructions</i></b>	<p>Extraction machines / truck mounts:</p> <ol style="list-style-type: none"> <li>1. Dilute with water in machine / sprayer.</li> <li>2. Pre-Spray using Techtron MP, Super Plus or Traffic HD</li> <li>3. Allow dwell time of approximately five minutes</li> <li>4. Run the wand or hand tool quite slowly across surface applying rinse.</li> <li>5. Follow over same area with extraction only. Repeat as required, surface should feel damp NOT wet.</li> </ol> <p>Sprayer – typically used for rotary cleaning methods:</p> <ol style="list-style-type: none"> <li>1. Follow steps 1, 2 &amp; 3 from extraction section.</li> <li>2. Spray on to surface to cover but NOT saturate.</li> </ol>
<b><i>Hints &amp; Tips</i></b>	<p><i>Use CFT Fibre &amp; Fabric Rinse after spot cleaning.</i></p> <p><i>Can be used for neutralisation of urine staining</i></p>
<b><i>Precautions</i></b>	<p><b>Use all PPE advised in MSDS and COSHH Assessment</b></p> <p>Always test fabric prior to application.</p>