

User Guide

Final Dressing

22001144/6x500ml

| | |
|---------------------------------------|---|
| <i>Application</i> | Restorer and Finisher for Plastics and Coated Surfaces |
| <i>Features & Benefits</i> | <ul style="list-style-type: none"> • Quick and easy finishing of surfaces and equipment • Excellent economy in use • Removal of oil marks and light contamination |
| <i>Dilution</i> | This product is supplied ready to use. |
| <i>Equipment Required</i> | <ul style="list-style-type: none"> • Soft cloth • Polythene bag (for storage of impregnated cloths) |
| <i>Use Instructions</i> | <ol style="list-style-type: none"> 1. Apply a little Rozone Final Dressing directly to a cloth and massage cloth to impregnate with dressing. 2. Rub cloth over items which have been cleaned, paying attention to profiled surfaces. 3. Buff up for a fine shine. |
| <i>Hints & Tips</i> | <i>Keep impregnated cloth in a plastic bag for further use.</i> |
| <i>Precautions</i> | Always follow safety advice on label or safety data sheet. |